

Target Net

#410392

Tools Needed

None.

Parts Needed

Bungee cords, cable ties or rope.



Step 1

Unfold the net. Hang from goal post or other structure with bungee cords or cable ties (not included).

Cautions and Suggestions for Safe Use

- Set up Net so that the bottom edge overlays the ground. Net should never be stretched taut, but should hang in loose position when in use.
- Practice nets should be carefully inspected for broken meshes or other apparent weaknesses before each use.
- Never use Net to catch people.
- Do not set up near solid objects against which the ball can strike and bound back. Net should be at least four feet from all bystanders, ceilings, walls or solid objects. For greater safety factor, allow maximum distance possible.
- Spectators must NOT stand in back or near sides of net while in use.
- Practice from one side of the Net only.
- As time goes by, some meshes of Net do wear and break from use or vandalism. These should be repaired so balls do not escape.
- Your Rogers Target Net will last longer if properly stored when not in use.
- User assumes all risk of injury.



ASSEMBLY INSTRUCTIONS



Champions aren't born.
They're made.

