



ASSEMBLY INSTRUCTIONS

Field Cart

410397


Tools Needed
7/16"
wrench and
pliers.



Step 1
Insert a cotter pin in each of the two interior holes in the axle.



Step 2
Slide a rectangular frame onto the axle.



Step 3
Slide a spacer tube and washer (in that order) onto the axle.



Step 4
Slide wheel onto axle. Slide on a washer and secure with cotter pin.

Step 5
Repeat Steps 2-4 on the other side.



Step 6
Slide the U-shaped bottom frame connector into place (do not bolt at this point).




Step 7
Slide the Vest Bag onto the L-shaped side rail that has no flat bar extending from the bottom.



Champions aren't born.
They're made.


Step 8

Slide the Chain and Down Marker Bag on the side rail with the flat bar at the bottom. Slide the attachment sleeve over the flat bar and secure with Velcro™ strap.




Step 9

Insert the side rails into the bottom frame connector.



Step 10

Bolt each side rail to the bottom frame connector using the 1/4 x 1 1/2" bolts.



Step 11

Slide the handle in place.



Step 12

Bolt the handle to each side rail with 1/4 x 1 1/2" bolts.



Step 13

Place the bottom plate on the frame and secure with four 1/4 x 1-3/4" bolts.



Maintenance

- Touch up scratches with semi-gloss black paint.

TIP: Your Rogers Athletic equipment will last longer if it is properly stored when not in use.